

## C. Replacement of Transparent Pane

### Removal:

1. Remove the license plate light.
2. Unscrew the two oval-head countersunk screws with hexagon nuts and take off the transparent pane (84) together with the seal (85) (see Fig. 82 — 12/1).

**Note:** The left housing has only one transparent pane on the inner side but the right housing

which illuminates the nationality plate has a further transparent pane fitted on the outer side.

### Installation:

3. Installation is the reverse of the removal procedure.