

## Transmission — Group 26

Designation	Order No.
Special wrench SW 17 mm, extra long, for the screws fixing the clutch housing to the engine	000 589 05 03 *
Assembly fixture, two parts, for the stop plate	191 589 02 31
Fitting bolt for the needle bearing of the shifting shaft	187 589 02 39
Fitting sleeve for the sealing ring of the shifting shaft in the transmission case top cover	187 589 05 61
Fitting bolt for the sealing ring of the shifting shaft in the transmission case top cover	187 589 03 39
Fitting bolt for the end cover in the transmission case top cover	187 589 01 39
Fitting bolt for the shift rail in the transmission case top cover	136 589 09 61
Installing sleeve with installing arbor for the sealing ring of the drive shaft in the transmission case front cover	198 589 00 61
Retaining fixture for 1st and 2nd speed gear	136 589 14 61
Retaining wrench for three-way flange	or 136 589 38 61
	187 589 00 31
	or 187 589 08 07
Crowfoot wrench socket for grooved nut of main shaft (three-way flange)	186 589 11 07
Bell-shaped puller for three-way flange	136 589 03 33
Tester and dial gage holder for measuring the run-out of the three-way flange and for adjusting the wheel hub bearings	136 589 04 21
Pliers for the drive shaft snap ring	136 589 00 37
Puller for annular grooved bearing of the main shaft and the drive shaft	136 589 02 33
Fitting sleeve (31 × 36 × 62)	198 589 02 61
Fitting sleeve (31 × 36 × 80)	198 589 01 61
Puller for annular grooved bearing of the countershaft	187 589 06 33
Drift for installing and removing the countershaft and the annular grooved bearing	136 589 06 39
Retaining tool for removing the annular grooved bearing of the countershaft	136 589 11 61
2 removing levers	136 589 00 35
Puller for the reverse idling shaft	136 589 27 33
Crowfoot wrench for the grooved nut of the main shaft	120 589 04 07
Crowfoot wrench socket for the grooved nut of the main shaft	120 589 11 07
Installing arbor for the drive annular grooved bearing	136 589 07 39
Special wrench for the end cover for the shift lever	187 589 01 01
Torque wrench 0 — 13 mkg, 1/2" square	000 589 22 21 *
Flexible torque wrench 0 — 12 mkg (1/2" square)	000 589 24 21 *
Micrometer for 0 — 25 mm $\varnothing$ for measuring shims etc.	000 589 06 19 *
Feeler gage 0.03 — 1.0 mm for measuring the end play of the individual speed gears	000 581 01 30 *
Micrometer depth gage 0 — 60 mm range	000 589 13 21
Dial gage, 10 mm travel, 1/100 mm reading accuracy	000 589 14 21 *
Dial gage holder	—
Internal micrometer for 18 — 35 mm $\varnothing$ (for reverse idling gear bore)	000 589 02 19 *
Internal micrometer for 35 — 60 mm $\varnothing$ (for speed gear bore)	000 589 13 19 *
Micrometer 25 — 50 mm $\varnothing$ (for main shaft bearing surfaces)	000 589 07 19 *

## Pedals — Group 29

Designation	Order No.
Internal micrometer for 18 — 25 mm $\varnothing$ (for the bores of the bearing bushings, for clutch and brake pedal)	000 589 02 19 *
Micrometer 25 — 50 mm $\varnothing$ (for outside diameter of the mounting tube)	000 589 07 19 *
Adjustable reamer for 27 mm $\varnothing$ for reaming the bearing bushings	