

## Removal and Installation of the Sliding Window in the Right or Left Rear Door

### Removal:

1. Remove the door trim panel (see Job No. 72—7).
2. Lower the sliding window until the fixing screws for the sliding window at the lower channel become accessible through the assembly holes (3) of the door inner panel (see Fig. 73—8/1). Screw out the fixing screws.

3. Push the window glass upward and turn it 90° within the window shaft. Then carefully take the glass out through the window opening.

### Installation:

4. Installation is the reverse of the removal procedure.