

## Removal and Installation of Left or Right Front Seat

**Removal:**

1. Disengage the seat adjuster, push the front seat forward out of the guide racks, and take out the seat.

**Installation:**

2. Fit the front seat on the guide racks from

the front. Push down the handle of the seat adjuster and push the front seat toward the rear until it is in the desired position. Release the adjuster handle and check whether the adjuster is locked by lightly rocking the seat back and forth.

## Removal and Installation of Bench Driving Seat

**Removal:**

1. Move the bench driving seat to its most forward position. Unscrew the rear connecting screw between the sliding seat fitting and the seat upholstery at all three fittings.

**Note:** The bench driving seat can only be removed together with the three sliding seat fittings left, right, and center.

2. Move the bench driving seat to its rearmost

position. Working from the front, unscrew the fixing screws at the side at all three fittings between the seat upholstery.

3. Then unscrew the two front fixing screws at all three fittings. Take the bench driving seat out together with the fittings.

**Installation:**

4. Installation is the reverse of the removal procedure.