

### Control Adjustments — Group 30

Designation	Order No.
Hook wrench for the installation and removal of the choke control	136 589 02 05

### Springs and Shock Absorbers — Group 32

Designation	Order No.
Spring tensioner for front springs, including guides	120 589 01 31
Spring tensioner for rear springs	120 589 05 31

### Front Axle — Group 33

Designation	Order No.
Bell-shaped puller for the ball-heads of the outer tie-rods and the center tie-rod	186 589 10 33
Remover and installer for the hub cap of the front wheel hub	180 589 00 33
Bell-shaped puller for the front wheel hub	136 589 15 33
Holding device for assembling and disassembling the steering knuckles	BE 10 515
Assembly fixture for the steering knuckle supports	120 589 01 61
Assembly fixture, 4 parts, for bearing and sealing ring of the front wheel hub	120 589 03 61
Testing gage for measuring the wheel hub bearing play and for measuring the run-out of the threeway flange at the transmission	136 589 04 21 *
Forcing arbor for the king pin bushings	136 589 09 39
Adjustable Hunger reamer 19.5—22.5 mm $\phi$ , Model U, for king pin bushings	000 589 03 53
Alignment gage for the upper control arm	120 589 04 21
Alignment gage for the lower control arm	120 589 05 21
Checking gage, two parts, for the front axle support	120 589 09 23
Supplementary gage for the two-part checking gage for the front axle support	120 589 10 23
Pressure spindle for the front axle support	120 589 00 27
Torque wrench 0—6 mkg ( $\frac{1}{2}$ " square) (for tightening the screws fixing the front axle support to the chassis base panel)	000 589 27 21 *
Protective cover for left front fender	000 589 39 98
Protective cover for right front fender	000 589 40 98
Adapter for car jack for raising and lowering the front of the car at the sub-frame	BE 10 986 *
Lifting rig for raising and lowering the front and rear part of the car	BE 10 989 *
Adapter for stands, for ensuring proper support at chassis base panel	BE 10 994 *
Tail wheel for holding and transporting the engine together with transmission and sub-frame	BE 10 990 *
Bridge for engine at the front for removal and installation of the sub-frame	BE 10 988 *
Bracket for transmission or engine at the rear (to be made by repair shop) (see sketch on Page 33—1/2)	*
Special wrench for caster adjustment	180 589 00 05
Spring tensioner for front spring	120 589 01 31 *
Center check screw for the steering	186 589 00 23
Wheel base measuring gage	136 589 07 21
Camber and caster gage	180 589 02 21
Check gage for front axle positioning	180 589 02 23
Track measuring gage, mechanical, for passenger cars and trucks up to 3.5 tons	000 589 05 21
	or 000 589 72 21
Optical axle gage, Exacta	000 589 42 21