

<b>Accelerating pump</b>	07—0/11	<b>Blower,</b>	
Acceleration test	00—4/10	right, for air-conditioning	83—4/1
Accelerator pedal, adjustment	30—3	toggle switch for	82—17
Acid level and acid density of battery	54—10/1	Blower and scoop for air-conditioning	83—4/1
Adjustment of brake shoes	42—10/1	Body center pillar	76—1
Adjustment and assembly data	00—2/1	Body noise, hints for elimination	73—20/1
Air-conditioning system		Body parts, cleaning and care	98—3/1
air duct and heat exchanger	83—6	Bowden cables for the regulating valve	
flap for air duct	83—6	of the heat exchanger and the flap	
insect screen	83—7	in the air duct	83—13/1
scoop and blower	83—4/1	Bracket for torque arm	
subsequent installation of blower		Brakes, technical specifications	00—1/5
at the right side	83—4/1	Brake adjustment, automatic	42—0/8
Anodized parts, cleaning and care	98—2	Brake cable	
Arm rest	72—6	replacement of center brake cable	42—19/1
ATE Power Brake T 50		replacement of rear brake cable	42—19/2
description	42—0/9	Brake drums, reconditioning	42—12
checking	42—2/4	Brake fluid reservoir	42—1/2
maintenance	42—15/5	Brake hose	
removal and installation	42—14/1	connection to brake anchor plate	01—2/3
subsequent installation	42—15/1	retaining spring	01—2/3
Automatic brake adjustment		Brake lever of hand brake	42—18/2
disassembly and reassembly	42—10/1	Brake light and tail light	82—13
Automatic vacuum control of distributor	15—23/4	Brake light switch	54—14
Axle displacement, lateral	40—3/12	Brake line system, checking	42—2/2, 42—13/1
Axle gage		Brake linings	
mechanical	40—3/16	checking	42—2/3
optical	40—3/16	replacement and re-surfacing	42—11/1
Axle positioning distance	40—3/11	Brake master cylinder	
		disassembly and reassembly	42—4/1
		removal and installation	42—3/1
		with bleed screw	42—1/2
		Brake pedal	29—10/1
		Brake pedal free play	42—2/3
		Brake shoes	
		adjustment	
		checking	42—2/3
		front, removal and installation	42—8/1
		rear, removal and installation	42—9/1
		Brake system	
		bleeding and flushing out	42—1/1
		bleeding with ARC 50 Power bleeder	42—1/5
		bleeding with ATE Filler and	
		Bleeder AW 34 204	42—1/6
		bleeding without special equipment	42—1/3
		checking	42—2/1
		description	42—0/3
		flushing out with special equipment	42—1/8
		general	42—0/1
		maintenance and repair	42—0/13
		trouble-shooting hints	42—16/1
		Brake wheel cylinder	
		disassembly and reassembly	42—7/1
		front, removal and installation	42—6/1
		rear, removal and installation	42—5/1
		rear, with 15/16" Ø	42—6/2
		Bulbs,	
		set of bulbs	54—0/1

Bumpers			
end bars	88—5/1		
front or rear	88—5/1		
<b>Cable harness</b>			
generator to regulator, appendix	54—4		
generator to regulator, circuit diagram	54—4		
generator to regulator, removal and installation	54—4		
for reversing light switch	54—5		
for steering tube, appendix	54—3/1		
for steering tube, removal and installation	54—3/2		
<b>Camber</b>			
front wheel, adjustment	40—3/2		
rear wheel, adjustment	40—3/4		
<b>Camshaft</b>			
checking the adjustment	01—3/17		
compensating washer	01—4/9		
end play	01—4/9		
grinding	05—5/4		
overhaul stages	01—5/1, 01—5/5		
re-bedding	05—5/6		
removal and installation	01—4/5, 01—4/7		
sprocket	01—4/5		
<b>Camshaft bearing</b>	01—4/7, 05—5/6		
overhaul stages	05—5/5		
play	05—5/4		
<b>Car enamel, touching-up and refinishing</b>	98—1/3, 98—1/5, 98—1/6		
<b>Car finish</b>			
cleaning, care and repair	98—1/1		
polishing and conditioning	98—1/2		
repair	98—1/1		
washing	98—1/1		
<b>Car measurements</b>	40—3/15		
<b>Car radio</b>	82—20/1		
<b>Carburetor</b>			
accelerating pump, description	07—0/11		
adjustment	01—4/3		
adjustment in countries above 2000 m altitude	07—0/13		
adjustment of idle	01—3/24		
arrangements of jets	07—3/1		
ball valve in mixing tube holder	07—0/11		
closing plug for the float chamber ventilation	07—3/5		
component parts	07—0/14		
description	07—0/1		
description of float chamber ventilation	07—0/11		
description of idle system	07—0/8		
description of normal running condition	07—0/9		
description of starter mechanism	07—0/4		
disassembly and reassembly	07—3/1		
jets	07—3/1		
measurement and adjustment of fuel level	01—3/19, 01—3/20 a		
measurement and adjustment of injection amount	01—3/20		
removal and installation	01—4/3		
shock-absorber	07—3/2, 07—3/4		
starter rotary slide valve	07—3/3		
technical specifications	07—0/13		
trouble-shooting hints	01—3/21		
<b>Caster</b>	40—3/5		
<b>Center pillar</b>	76—1		
<b>Centering of clutch pedal shaft</b>	01—1/5, 29—5/3		
<b>Centering of propeller shaft</b>	41—1/3		
<b>Center tie-rod</b>	46—9		
<b>Chain guide</b>			
in the crankcase	01—4/29, 01—4/35		
in the cylinder head	01—4/5		
<b>Chain tensioner</b>			
bleeding	01—4/10		
with new tension sprocket bearing and higher web	05—5/8		
removal and installation	01—4/5		
testing	05—5/7		
<b>Charging light</b>			
description	15—10/2		
removal and installation	15—15		
<b>Chassis base panel assembly</b>			
checking	61—1/3		
dimensions	61—1/7		
<b>Chassis base panel gage</b>			
assembly	61—1/2		
description	61—1/1		
<b>Chassis number, model plate, location</b>	VI		
<b>Check plates for crankshaft</b>	01—4/30		
<b>Checking the brake line system</b>	42—2/2		
<b>Choke control</b>	30—6/1		
<b>Chromium-plated parts, cleaning and care</b>	98—2		
<b>Cigar-lighter</b>			
removal and installation	82—11		
replacement	82—11		
<b>Circuit diagram</b>	54—0/2		
<b>Cleaning</b>			
chromium-plated parts	98—2		
the cooling system	50—2		
car finish	98—1/1		
various body parts	98—3/1		
<b>Clock</b>	54—12		
<b>Closure angle, distributor contact</b>	01—3/10		
<b>Closure angle meter</b>	01—3/10		
<b>Clutch</b>			
adjustment data	25—1/3		
actuating mechanism	29—1		
disassembly, inspection and reassembly	25—4/1		
grinding clutch face of flywheel	03—5/12		
removal and installation	25—1/1		
technical specifications	00—1/4		
<b>Clutch bearing</b>	25—6, 26—1/2		
<b>Clutch disk (driven member)</b>	25—5/1		
<b>Clutch housing</b>	26—4/5		
<b>Clutch pedal</b>			
removal and installation	29—4		
adjustment of clutch pedal free play	29—3/1		
<b>Clutch pedal shaft</b>	29—5/1		
<b>Clutch springs</b>	25—4/2		
<b>Compensating washers for rear axle suspension bolts</b>	35—4/6		
<b>Compound carburetor for Model 190, description</b>	07—0/1		
<b>Compression chamber</b>	01—3/3, 01—5/6		
<b>Compression measurement</b>	01—3/3		
<b>Compression ratio, low, for fuels with a lower anti-knock value</b>	01—5/6		

Conditioning of car finish	98—1/2
Connecting rods	01—4/33
reconditioning and re-bushing	03—5/6
squaring	03—5/9
Connecting pins, tightening up	01—4/32, 03—5/8
Contact breaker arm, measurement of spring pressure	01—3/11
Contact breaker points, removal and installation	15—23/3
Contactor for automatic switch-off of fog lights	82—19/3
Control arm	
checking	33—5/2
pivot pins	33—4/6, 40—3/3
tightening lower fixing screws	33—2/3
Control cable, starter	15—1/2
Control knob mounting plate	68—1
Control shaft	30—1/1
Conversion tables (mm to inches)	00—3/1
Cooling system	
capacity	50—1/3
cleaning	50—2
Cooling water	
circulation	50—0/1
rust and scale inhibitors	50—1/3
temperature	50—0/1
thermometer	54—11/2
Countershaft of transmission	26—4/13, 26—4/15
Counterweight on crankshaft	01—4/28
Covering on trunk compartment	
cover plate	69—5
Cowl and insulating panels	68—3/1
Cowl panel front, at radiator	88—4
Crankcase	
cleaning, pressure-testing and surface-grinding	01—5/3
disassembly and assembly	01—4/35
Crankshaft	
annular grooved bearing assembly	01—4/36
balancing, with counterweight and flywheel installed	03—5/13
grinding	03—5/1
overhaul stages	01—5/1, 03—5/2
re-bedding	03—5/3
removal and installation	01—4/29
seal	01—4/32
Crankshaft bearing	01—4/30
Crankshaft end play	01—4/31, 03—5/4
Crankshaft timing gear, compensating ring	01—4/31
Cylinder bores	
boring and honing	01—5/5
overhaul stages	01—5/1
Cylinder covers for engine water jacket	01—4/35, 01—5/3
Cylinder head,	
machining and pressure-testing	01—5/6
removal and installation	01—4/5
tightening the fixing screws	01—4/8
tightening up the fixing screws	01—4/12
<b>D</b> amper springs, replacement	14—5/1
Data sheet	
for fuel consumption	00—4/6
for oil consumption	00—4/9
for vehicle measurement	40—3/23
Deceleration	42—0/3

Deceleration values	42—0/3
Dimmer resistance for instrument lighting	54—18
Dimmer switch, foot-operated	54—14
Disk, clutch (driven member)	25—5/1
Disk-type horn	54—15/1
Distributor	
adjustment curve	01—3/15, 15—23/2
removal and installation	01—4/19
Distributor bearing	01—4/19
Distributor coupling	15—23/4
Distributor contact gaps	
measurement and adjustment with a feeler gage	01—3/10
measurement with a closure angle meter	01—3/10
Distributor drive, removal and installation	01—4/21
Distributor drive and oil pump	
drive	01—4/21, 18—4/1
Distributor rotor arms, checking	15—24
Divided window reveal molding	72—3/1
Dome light	82—10
Door, front or rear	72—21/2
Door check mechanism	72—2/1
Door handle	72—16/1
Door lock	72—18
adjustment	72—21/1
Door trim panel	72—7
Drip molding (garnish molding)	69—4
Drive shaft (transmission)	26—4/11, 26—5/4
Dust covers for shock-absorbers	32—1/4
<b>E</b> lectrical system	
assemblies and instruments	54—0/1
car body	82—1/1
engine	15—1/1
Electrode gap	01—3/5
End play	
camshaft	01—4/9
crankshaft	01—4/31, 03—5/4
Engine	
compression ratio	01—3/3, 01—5/6
disassembly and reassembly	01—4/1
lubrication	18—5/1
removal and installation	01—0
removal and installation, together with transmission	01—1/1
removal and installation, together with transmission and sub-frame	01—2/1
side views	01—4/2
testing and repairing	01—5/1
technical specifications	00—1/1
tune-up	01—3/1
Engine compartment light	82—18/1
Engine compartment panels	68—3/1
Engine number, model plate, location	VI
Engine suspension,	
front	01—1/4, 22—1
front rubber mounting	22—1
rear	01—1/4, 24—1
rear rubber mounting	24—1/1
Exhaust assembly	49—1/1
<b>F</b> an	
distance between fan top and radiator	50—1/2
removal and installation	01—4/18
tropical	01—4/18

Fender	
front fender	88—1/1
rear fender	88—2/1
Fittings, seat-back	
general	91—3/1
reclining-seat fittings for front seat	91—3/2
standard	91—3/3
Fittings, for sliding roof	78—2
Flap for air duct	83—6
Flash direction signal	82—3
Flash signal mechanism	
removal and installation, for	
flash direction signals	54—16/1
removal and installation, for	
upper beam flash signal system	54—16/1
Flash signal switch, upper beam	54—17
Flash stroboscope, engine speed values	01—3/14
Flexible window run channels at	
front door	72—12/1
Float chamber ventilation	07—0/11
Float needle valve, testing for	
leakage	01—3/18, 07—3/3
Fluid reservoir	42—1/2
Flywheel	
grinding clutch face	03—5/12
re-balancing	03—5/14
removal and installation	01—4/36
Fog lights	
adjustment	82—2/2
installation	82—19/1
contactor for automatic switch-off	82—19/3
Foot dimmer switch	54—14
Front axle, technical specifications	00—1/4
Front axle bearing	33—4/2, 33—4/5
Front axle half	
checking and repairing	33—5/1
removal and installation	33—2/1
Front axle number, location	VII
Front axle support	33—1/1
checking	33—8/1
Front brake shoes, removal and	
installation	42—8/1
Front engine suspension	01—1/4, 22—1
Front fender	88—1/1
Front grease seal, for crankshaft	01—4/32
removal and installation	01—4/36
Front or rear door	72—21/2
Front shock-absorber, removal and	
installation	23—2
Front springs	
color code for	32—0/2
harder, for bad roads	32—0/5
removal and installation	32—4/1
test values	32—0/2
Front wheel brake cylinder, removal	
and installation	42—5/1
Front wheel camber, adjustment	40—3/2
Fuel consumption	
according to German Standard DIN	
70 030	00—4/2
level-road consumption	00—4/1
overall fuel consumption	00—4/1
partial load consumption	00—4/2
test	00—4/1
Fuel consumption curve	00—4/2

Fuel feed pump	
checking	09—5/5
disassembly and reassembly	09—5/3
measurement and adjustment of	
pressure	01—3/17
Fuel full-flow filter	47—6
Fuel gage	
checking	47—1/3, 47—3
fault tracing	47—4/1
instrument cluster	54—11/2
Fuel level, measurement and adjustment	01—3/19
Fuel level indicator,	
testing	47—3
removal and installation	47—2
Fuel-mileage tester	00—4/4
Fuel pump	
dust-proof	01—4/24
removal and installation	01—4/24
Fuel tank	
checking and repairing	47—5
removal and installation	47—1/1
removal and installation of fuel level	
indicator	47—2
testing fuel level indicator	47—3
Fuse box, connections at	54—0/3
<b>G</b> arnish molding at ledge	72—20
Gear train, transmission, removal	
and installation	26—4/10
Gearshift mechanism, adjustment	26—3/1
Generator	
description	
disassembly and assembly	15—13/1
mounting	01—4/13
removal and installation	01—4/13, 15—11/1
servicing hints	15—12/1
subsequent installation of a 300 watt	
generator	01—4/15
test values	15—16/3
testing	15—16/1
trouble-shooting hints	15—17/1
Generator and regulator, description	15—10/1
Glove compartment cylinder lock	68—4/1
Glove compartment lid	68—4/1
Glove compartment light	68—4/3
Grease seal	
front, removal and installation	
(for crankshaft)	01—4/32
for the steering assembly	46—6
in the steering, removal and	
installation	46—6
Ground lead at distributor	01—4/19
Guard plates	
general	52—1/1
for step bearings	52—1/5
(cover plate for radiator)	52—1/3
for brake master cylinder	52—1/4
for clutch and transmission	52—1/4
for rear axle (towing hook)	52—1/5
Guide pin, shift tube	26—11/1
<b>H</b> and brake	
adjustment	42—19/3
checking	42—2/3
lever	42—18/2
ratchet and hand brake	42—18/1

Head lights				Intake manifold	
adjustment	82—2/1			replacement of damper spring	14—5/1
removal and installation	82—1/1			replacement of heater valve and shaft	14—5/1
replacement of bulbs	82—1/2			replacement of heating spiral	14—5/1
removal and installation of				Intake manifold and exhaust manifold	
head light glass	82—1/2			removal and installation	01—4/4
Head light lower beam flash signal				Interference suppression, methods	82—20/1
system	54—16/2				
Headlining	69—1			<b>J</b> ets, carburetor	07—3/1
front headlining	69—2/2			Jointing disk, of steering coupling	46—13/1
sliding roof version	69—2/1				
removal and installation of left,				<b>K</b> ing pin inclination	40—3/5
right, and rear headlining					
(sliding roof version)	69—2/1			<b>L</b> evel-road consumption	00—4/1
Heat exchanger	83—1			License plate light	
regulating valve	83—2/1			removal and installation	82—12/1
Heater valve and shaft, replacement	14—5/1			replacement of bulb	82—12/1
Heating, underseat	83—10/1			replacement of transparent pane	82—12/2
Heating spiral, replacement	14—5/1			Lid, glove compartment	68—4/1
Helical gear				Light, glove compartment	68—4/3
transmission	26—4/10, 26—5/3			Lock, glove compartment	68—4/1
distributor drive	01—4/21			Lock, rear compartment lid	75—2
Hood	88—6			Lubrication and maintenance	00—5/3
Hood hinge	88—7			lubrication and maintenance chart	00—5/9
Horn assembly	54—15/1			lubricating points	00—5/1
disk-type horn	54—15/1			oils and greases for the various	
three-tone horn assembly	54—15/2			assemblies	00—5/1
two-tone horn assembly	54—15/1				
Hydraulic system				<b>M</b> achining of cylinder head	01—5/6
bleeding the hydraulic system with				Main bearing	01—4/30
ARC 50 Power Bleeder	42—1/5			Main bearing screws, tightening	01—4/30
bleeding with ATE Bleeder AW				Main shaft, transmission	26—4/13, 26—4/16, 26—5/2
34 204	42—1/6			Main wiring harness	
flushing out with special flushing				diagram, appendix	54—1/2
equipment	42—1/8			circuit diagram	54—1/1
				removal and installation	54—1/9
<b>I</b> dle adjustment	01—3/24			Maximum speed test	00—4/11
Idle adjustment screw	01—3/24			Measurements of car	40—3/15
Idle mixture adjustment screw	01—3/24			Mercedes star, flexible-mounted	88—8
Idling gear shaft for distributor drive	01—4/21			Metal sheen enamels	98—1/4
Ignition				Misalignment of rear axle	40—3/12
adjustment, (octane number com-				Model plate, engine number and	
pensator	01—3/12, 01—3/15, 30—8/1			chassis number	VI
adjustment, using timing light	01—3/12			Motor for windshield wiper	82—4
setting, with flash stroboscope	01—3/14			Mounting of tires	40—1/1
Ignition coil, checking	15—22			Mounting plate for the control knobs	68—1
Ignition curve	01—3/15, 15				
Ignition lead, checking	15—24			<b>O</b> il consumption test run	00—4/7
Ignition lead connectors, checking	15—24			Oil filling of water pump	20—5/3
Ignition switch	15—21/1			Oil filter	
Ignition system, description	15—21/1			disassembly, cleaning and re-	
Inhibitors,				assembly	18—5/6
rust and scale inhibitors	50—1/3			removal and installation	01—4/25
Insect screen	83—7			Oil pan	01—4/26
Insects,				Oil pressure gage	54—11/2
removal of dead insects on the				Oil pressure with the engine idling	18—5/2
car finish	98—1/2			Oil pump	
Inspection light,				removal and installation	01—4/27
socket, in engine compartment	54—20/1			repair	18—5/3
Instrument cluster	54—11/1			Oil pump drive, removal and installation	01—4/21
Instrument lighting	54—11/1			Oil pump gear play	18—5/3
push-pull switch and dimmer resistance	54—18			Oil relief valve	
Insulating flange for carburetor	01—4/3			in crankcase, cleaning and checking	18—5/5
Insulating panels, cowl	68—3/1			removal and installation in crankcase	01—4/26
(in engine compartment)				in oil filter	18—5/7

Oil thrower ring, crankshaft	01—4/28, 01—4/29
Oil shock-absorber for carburetor	07—3/4
Optional extras, list of	00—6/1
Overall fuel consumption	00—4/4
Overhaul stages	
camshaft	01—5/1, 05—5/5
camshaft bearing	01—5/1, 05—5/5
crankcase	01—5/1
crankshaft	01—5/1, 03—5/2
pistons	03—5/10
valve guide	01—5/8
valve seat ring	01—5/9

<b>P</b> anels in engine compartment	68—3/1
Parking light, toggle change-over switch	82—16
Partial load fuel consumption	00—4/2
Partition plate at crankcase	01—4/35
Piston pin bushing, replacement	03—5/7
Piston pin play	03—5/7
Piston rings	03—5/10, 01—4/33
Pistons	
fitting piston, together with rings	03—5/10
removal and installation	01—4/33
Pivot bearing for steering relay arm	46—11/1
Pivot point distance	40—3/10
Plate with drive mechanism for windshield wipers	82—5/1
Plate valve for radiator	50—1/2
Power brake, see ATE Power Brake	
Pressure-testing	
of crankcase	01—5/4
of cylinder head	01—5/6
Propeller shaft	
disassembly and reassembly	41—4/1
intermediate bearing	41—4/1, 41—1/1
removal and installation	41—1/1
universal joints	41—4/4
Propeller shaft and intermediate bearing	26—1/1, 41—4/1
Protective plate for front axle support and oil pan	52—1/2
Protective rail for the brake line and the fuel line	42—2/2, 52—1/4
Pulley, crankshaft	01—3/2, 01—4/28
Push-pull switch	
for instrument lighting	54—18
for windshield wipers	82—10

<b>R</b> adiator, removal and installation	50—1/1
Radiator cap	50—1/1
Radiator cover	50—4
Radiator plate valve	50—1/2
Radiator testing	50—1/1
Radio	
car radio	82—20/1
subsequent installation	82—20/1
trouble-shooting hints	82—20/2
Ratchet, removal and installation	42—18/1
Reaction second	42—0/2
Rear axle	
adjustment of taper roller bearings	35—4/17
axle tube	
checking	35—5/4
removal and installation	35—4/5

checking connecting pin	35—5/11
description	35—0/1
disassembly and reassembly	35—4/1
gear train	
adjustment	35—4/13
checking	35—5/9
disassembly and reassembly	35—4/19
removal and installation	35—4/10
removal and installation	35—1/1
slip coupling	
checking	35—5/11
disassembly and reassembly	35—4/23
sliding sleeve, lock for	35—4/3a
technical specifications	00—1/4
torque arm	
removal and installation	35—4/4
Rear axle housing	35—5/8
Rear axle number, location	VII
Rear axle shaft	
checking	35—5/2
with lock for sliding sleeve	35—4/3a
removal and installation	35—4/1
Rear axle support and suspension,	
checking	35—5/12
Rear brake cable, replacement	42—19/2
Rear brake shoes, removal and installation	42—9/1
Rear brake wheel cylinder, with a diameter of 15/6"	42—6/2
removal and installation	42—6/1
Rear compartment heating and underseat heating	83—10/1
Rear compartment lid	75—2
Rear compartment lid hinge	75—4
Rear compartment lid lock	75—2
Rear compartment lid weatherstrip	75—4
Rear doors	72—21/2
Rear engine suspension	01—1/4, 24—1/1
Rear fender	88—2/1
Rear reflectors	88—5/2
Rear shock-absorbers, removal and installation	32—3/1
Rear springs	
color code for	32—0/2
harder	32—0/6
removal and installation	32—5/1
test valves	32—0/4
Rear wheel camber, adjustment	40—3/4
Rear window	67—3
Re-charging of battery	54—10/3
Reclining-seat fittings	
bench driving seat	91—3/4
front seat	91—3/2
Regulating valve for heat exchanger	83—2/1
Regulator	
cable harness for	54—4
current regulator	15—10/1
description	15—10/1
removal and installation	15—15
test valves	15—16/3
testing	15—16/1
Reinforcement plates for shock-absorber	32—1/5
Relay shaft at shift tube	26—14/2
Reveal molding, windshield	67—2/1

Reversing light switch		disassembly	35—4/23
adjustment	26—4/5	Socket for inspection light (in engine compartment)	54—20/1
cable harness for	54—5	Solenoid switch for starter	15—2
Rocker arms, removal and installation	01—4/5	Spark plugs	
Rocker arm blocks, tightening up		approved	01—3/4
screws for	01—4/11	cleaning and testing	01—3/7
Rocker arm block guide sleeves	01—4/10, 01—4/38	electrode gap	01—3/5
Rocker arm and rocker arm mounting,		general	01—3/4
testing	05—5/11	removal and installation	01—3/9
Rocker plate	88—3	testing	01—3/7
Roller chain, twin	01—4/37	Specifications, see Technical Specifications	
Rolling diameter	40—3/5	Speedometer	54—11/2
Roof light	82—10	Speedometer drive gear	26—4/9
Rotary light switch	82—15/1	Springs	32—0/1
Rubber cuff for steering shock-absorber	46—10/2	front, color code for	32—0/2
Rubber molding for wiper blade	82—8	front, harder, for bad roads	32—0/5
Rubber mounting		front, removal and installation	32—4/1
front, for engine suspension	22—1	front, test values	32—0/2
rear, for engine suspension	24—1/1	rear, color code for	32—0/2
sub-frame suspension	33—1/3	rear, harder, for bad roads	32—0/6
<b>S</b> cale on the counterweight	01—3/13	rear, removal and installation	32—5/1
Scare second	42—0/2	rear, test values	32—0/4
Scoop and blower for air-conditioning system	83—4/1	technical specifications	00—1/5
Seat-back fittings		Spring plate, rear springs	32—5/2
general	91—3/1	Sprocket wheel, checking misalignment	01—4/9
reclining-seat fittings for front seat	91—3/2	Starter	
bench driving seat	91—3/4	description	15—1/1
standard	91—3/2	disassembly and assembly	15—4/1
Selector finger (transmission)	26—4/3	electrical testing	15—5/1
Selector lever shaft at shift tube	26—14/1	push-button switch	54—20/1
Sealing brush at front door	72—12/1	removal and installation	15—1/1
Sealing ring, fabric, crankcase	01—4/31	servicing hints	15—3
Sealing ring retainer, for valve stem sealing system	05—5/3	solenoid switch	15—2
Sealing strips, door outside and inside	72—10	trouble-shooting hints	15—6/1
Shaft plate		Starter mechanism of carburetor	07—0/4
at propeller shaft	41—1/2	Starter ring gear	03—5/12
Shift forks, at transmission	26—4/4, 26—5/5	Steering	
Shift tube bearing assembly	26—12/1	checking and repairing	46—5/1
removal and installation	26—12/1	description	46—0/1
repair	26—14/1	disassembly and reassembly	46—4/1
Shift tube and steering column jacket		removal and installation	46—1/1
length	26—15/2	Steering assembly units, checking of play	46—3
removal and installation	26—15/1	Steering column bracket	26—15/1, 46—7/1, 46—8/1
Shift tube guide pin	26—11/1	removal and installation with lock	46—8/1
Shift tube rubber bearing	26—14/2	Steering column jacket length	26—15/2
Shock-absorbers	32—0/7, 32—1/1	removal and installation	26—15/1
for bad roads	32—1/3	Steering gear, technical specifications	00—1/4
for carburetor	07—3/2, 07—3/4	Steering gear arm	46—13/1
front, removal and installation	32—2	Steering housing, checking	46—5/2
front, test values	32—1/2	Steering nut, checking	46—5/1
larger, for special-purpose vehicles	32—1/4	Steering relay arm	46—11/1
rear, removal and installation	32—3/1	Steering shock-absorber	
rear, test values	32—1/2	removal and installation	46—10/1
technical specifications	00—1/5	special export version	46—10/2
Sliding roof	78—1	Steering tube	
fittings	78—2	cable harness for	54—3/1
Sliding sleeve of rear axle, lock for	35—4/3a	removal and installation	46—7/1
Sliding window		Steering wheel	46—2/1
front door	72—9	Steering worm, checking	46—5/1
rear door	73—9	Step bearing for front axle or torque arm,	
Slip coupling of rear axle		welding of	61—1/5
checking	35—5/11	Step bearing for the torque arm	35—1/3, 61—1/5
		Stop light and tail light	82—13
		Stop light switch	54—14

Stopping distance	42—0/1
Stroboscope, flash	01—3/14
Sub-frame	
mounting at chassis base panel	01—2/4, 33—1/3
removal and installation	33—1/1
Sub-frame suspension, rubber mounting for	33—1/3
Suction tube, removal and installation	01—4/4
Sun visor	81—1
Surface-grinding of crankcase	01—5/3
Synchronizing rings of transmission	26—5/4

## **T**aper roller bearings of rear axle,

adjustment	35—4/17
Tappet clearance, adjustment	01—3/2, 01—4/11
Tar stains, removal	98—1/1
Tail light and brake light	82—13
Tail light wiring harness	
appendix	54—2/1
circuit diagram	54—2/1
removal and installation	54—2/3
Technical specifications	
brakes	00—1/5
capacities	00—1/6
carburetor	07—0/13
clutch	00—1/4
dimensions	00—1/6
electrical equipment	00—1/5
electrical equipment at engine	00—1/2
engine	00—1/1
engine adjustment data	00—1/3
front axle	00—1/4
fuel system and mixture control	00—1/2
rear axle	00—1/4
shock-absorbers	00—1/5
speeds, consumption figures and operating conditions	00—1/7
springs	00—1/5
steering gear	00—1/4
transmission	00—1/4
weights	00—1/6
wheels and tires	00—1/5
Tension sprocket, removal and installation	01—4/5
Tension sprocket bearing, new	05—5/8
Tension sprocket and bearing, repair	05—5/10
Thermometer, for cooling water	54—11/2
Thermostat	50—6/1
Threaded bushings of front axle	33—5/2
Three-element voltage-current regulator	
description	15—10/1
electrical testing	15—16/1
removal and installation	15—15
Three-way flange at the transmission,	
check for run-out	26—5/5, 26—4/9, 41—1/2
Three-tone horn assembly	54—15/2
Tie-rods	33—6/1
Timing gear, camshaft	01—4/5
Timing gear, crankshaft	01—4/31
Tire chains	40—0/5
Tire pressure	40—0/3
Tire wear	40—3/13
Tires	40—0/2
standard	40—1/1
tubeless	40—1/1
Toe-in	40—3/7

Toe-out	40—3/7
Toggle change-over switch for parking light	82—16
Toggle switch for blower	82—17
Torque arm, mounting on chassis	
base panel	35—1/4, 35—1/7
Torsion bar	32—6
Track rods	33—6/1
Trailer attachment	52—2/1
Transmission	
countershaft	26—4/13, 26—4/15
disassembly and reassembly	26—4/1
gear train	
removal and installation	26—4/10
grooved nut	26—4/9
inspection and repair	26—5/1
locking plates for transmission case	
front cover	26—4/7
locking plates for transmission case	
rear cover	26—4/9
main shaft	26—4/13, 26—4/16
main shaft with third speed gear	
on roller bearing	26—4/19
removal and installation	26—1/1
reverse drive gear stop	26—4/4
synchronizing units	26—4/14
technical specifications	00—1/4
Transmission case	
front cover	26—4/6
rear cover	26—4/7
top cover	26—4/1
Transmission number, location	VII
Trade-mark plate at steering wheel	46—2/1
Tropical fan	01—4/18
Twin roller chain	01—4/37
Tubeless tires	40—0/5, 40—1/1
Two-tone extra-loud horn assembly	54—15/1

<b>U</b> nderpressure valve of radiator	50—1/2
Underseat heating	83—10/1
Unit numbers, location	VII
Universal joints	
of propeller shaft	41—4/4
of rear axle	35—4/25
Upper beam flash signal switch	54—17
Upper beam flash signal system	54—16/1

## **V**alves

grinding	05—5/1
removal and installation	01—4/5
Valve cone halves	05—5/3
Valve guides	
checking and replacing	01—5/7
overhaul stages	01—5/8
Valve seat rings, replacement	01—5/9
Valve seats, machining	01—5/12
Valve stem, sealing	05—5/3
Valve timing	01—3/26
testing	01—3/25
Vee-belt of generator, tightening	01—4/14, 50—5
Ventilator, front door	72/13/1
Voltage regulator, description	15—10/1

## **W**asher for windshield,

electric with gear-type pump	67—5/3
with hand pump	67—5/1



Washing of car finish	98—1/1	Window regulator handle	72—6
Water pump		Window reveal molding	
oil filling	20—5/3	divided, tropical design	72—3/1
removal and installation	01—4/18	Window run channel, flexible	
repair	20—5/1	at front door	72—12/1
Weatherstrip		at rear door	73—12
front door	72—15	Windshield	67—2/1
rear door	73—15	Windshield washer	67—5/1
trunk compartment lid	75—4	Windshield wiper	
Wheel adjustment valves	40—3/12	removal and installation	
Wheelbase	40—3/11	of motor	82—4
Wheel camber	40—3/2	of wiper arm with wiper blade	82—6
front, adjustment	40—3/2	of plate with drive mechanism	82—5/1
rear, adjustment	40—3/4	rubber molding for rubber blade	82—8
Wheel hubs of front axle	33—4/2, 33—4/4	wiper blade	82—7
checking	33—5/3	Winter tires	40—0/5
adjustment	33—4/5	Wiper arm with wiper blade	82—6
Wheels		Wiper blade	82—7
adjustment	40—3/1	Wiring harness	
balancing, with tires fitted	40—2/1	generator to regulator, appendix	54—4
Wheels and tires	40—0/1	generator to regulator, circuit diagram	54—4
Window frame		generator to regulator, removal and	
at front door	72—14	installation	54—4
at rear door	73—14	for reversing light switch	54—5
Window regulator		for steering tube, appendix	54—3/1
for front door	72—8	for steering tube, removal and	
for rear door	73—8	installation	54—3/2