

Removal and Installation of Rear Compartment Lid Hinge

Removal:

1. Remove the rear compartment lid (see Job No. 75—1).
2. Unscrew the three hexagon tapping screws at each rear compartment lid hinge from

the trunk compartment cover plate and remove the hinge.

Installation:

3. Installation is the reverse of the removal procedure.

Removal and Installation of Rear Compartment Lid Weatherstrip

Removal:

1. Remove the cemented weatherstrip and carefully scrape off the remains of the rubber and the adhesive.

Installation:

2. Coat the groove around the rear compartment opening with Terokal Rubber Adhesive II and press the weatherstrip into the groove while it is still wet.

Note: The weatherstrip is cemented into the groove by means of a so-called two-component adhesive. The weatherstrip supplied as a replacement part has already been treated with Terokal Rubber Adhesive I.

The vulcanizing effect which produces a firm bond between rubber and sheet metal is brought about when the two components come into contact.