

Removal and Installation of Rear Seat and Rear Seat Back

Removal:

1. Lift the rear seat cushion at the front edge and take it out.
2. Unscrew the rear seat back from the trunk compartment.
3. Pull the upper edge of the seat back forward and detach the seat by pulling upward.

Installation:

4. Hang the rear seat back from above into the left and right hooks at the wheel arch

assembly. Then push the upper edge of the seat back toward the rear until the two stud bolts pass through the holes in the rear panel, and screw on the seat back from the trunk compartment.

5. Fit the rear seat cushion at an upward angle and install the two pins at the front lower edge in the holes in the seat upholstery provided for them. Then push the rear edge of the seat cushion down.