

Table 18

## FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
40	120 333 02 30	Pin	2	
41	120 333 01 80	Sealing ring	4	)
42	120 333 02 48	Threaded bushing (left, rear and right, front)	2	)
43	120 333 03 48	Threaded bushing (left, front and right, rear)	2	) for wishbone, ) inner
44	120 997 00 88	Grease fitting	4	)
45	120 333 04 74	Threaded pin with lubricating groove	2	)
46	181 333 01 80	Sealing ring	4	) for wishbone, ) bottom, at
47	181 990 00 55	Castle nut	2	) steering
48	-	Cotter pin 3x35 DIN 94	2	) knuckle support
		<u>WISHBONE, TOP</u>		)
49	120 330 04 07	Wishbone, top, left	1	
50	120 330 05 07	Wishbone, top, right	1	
51	120 333 00 30	Pin	2	
52	120 333 01 80	Sealing ring	4	)
53	120 333 02 48	Threaded bushing (left, front and right, rear)	2	)
54	120 333 03 48	Threaded bushing (left, rear and right, front)	2	) for wishbone, ) inner
55	-	Grease fitting B 8 DIN 71412	4	)
56	120 333 05 48	Threaded bushing with lubricating groove	2	
57	120 333 03 74	Eccentric pin	2	
58	181 333 01 80	Sealing ring	4	
59	120 990 13 40	Washer	2	

Table 18

## FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
59a	120 990 32 40	Adjusting washer	2	
60	120 330 01 87	Eccentric bushing	2	
61	-	Lock washer B 10 DIN 127	2	
62	-	Hex. nut M 10 DIN 934-5 S	2	
63	120 333 00 73	Locking plate	2	
64	-	Lock washer B 6 DIN 127	2	
65	-	Hex. -hd. screw M 6x10 DIN 933-8 G	2	
		<u>TIE ROD</u>		
66	120 330 07 03	Tie rod	2	when mounting take care that the grease fitting A 8 DIN 71412 is always mounted on outside (at disc wheel)
67	120 338 01 15	Tie rod jacket	2	
68	120 338 00 63	Tightening ring	4	
69	120 994 00 15	Locking plate	4	
70	120 330 05 48	Ball socket head (right-hand thread) (for tie rod, right, outside)	1	) ) grease fitting ) A 8 DIN 71412
71	120 330 04 48	Ball socket head (left-hand thread) (for tie rod, left, outside)	1	) mounted on ) inside )