

Table 28

STEERING

Group 46

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
46	180 540 00 09	Cable set	1	
47	120 990 00 77	Threaded pin (for jacket)	1	
48	120 993 08 01	Pressure spring (for steering column, top)	1	
		<u>STEERING WHEEL</u>		
49	120 464 04 01	Steering wheel, black)	1	
-	120 464 06 01) optional Steering wheel, black)	1	
50	-	Key A 6 x 4 x 20 DIN 6885	1)
51	120 994 03 12	Locking plate	1) for steering
52	-	Hex. nut M 18x1,5 DIN 936-5 S	1) wheel at
53	120 460 02 45	Contact plate	1) steering column
54	181 464 00 71	Clamping screw	5	
55	-	Cylindr. screw AM 4x25 DIN 84-5 S	1	
56	-	Cylindr. screw AM 4x15 DIN 84-5 S	2	
57	-	Lock washer 4 N 55 a	2	
58	186 460 03 40	Signal ring	1	
59	181 460 04 46	Stop lever	1	
60	181 464 00 90	Release spring	1	

Table 28

STEERING

Group 46

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
61	182 464 00 62	Washer	1	
62	181 464 00 28	Contact washer	1	
63	181 464 01 86	Contact plate	1	
64	153 464 00 23	Insulating plate	1	
65	186 993 37 01	Pressure spring	1	
66	153 464 00 72	Adjusting nut	1	
67	-	Cotter pin 1x18 DIN 94	1	
68	183 997 05 40	Rubber plate	1	
70	187 460 01 44	Manufacturer's mark (at steering wheel)	1	
71	-	Hex. -hd. screw M 6x15 DIN 933-8 G	6)))
72	000 990 27 91	Square-hd. locking nut M 6	6)for jacket at)dashboard
73	-	Washer A 6 DIN 9021	4))
73a	120 545 01 76	Washer	2)
74	120 460 08 37	Steering column bracket, compl. with lock	1	
75	000 462 00 32	Key	1	state number stamped into key when ordering

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
76	000 462 02 93	Ignition breaker	1	
77	000 462 03 23	Contact cap	1	
78	000 462 01 75	Pin, contact lifting	1	
79	000 462 02 70	Pin	1	
80	000 462 00 72	Nut	1	
81	-	Bulb M 12 V 3 W DIN 72601	1	
82	120 460 02 65	Tightening strap (for steering column bracket)	1	
83	-	Washer 8, 4 DIN 433	2) for steering column bracket at instrument panel
84	-	Toothed washer A 8, 4 DIN 6797	2	
85	-	Hex. nut M 8 DIN 936-5 S	2	
86	-	Hex. nut M 8 DIN 936-5 S	2) for steering column bracket at jacket
87	-	Washer 8, 4 DIN 125	1	
88	120 460 18 38	Pivot pin with bushing (for steering intermediate lever)	1	
89	120 463.02 50	Bushing	1	
90	-	Lock washer B 10 DIN 127	3) for pivot pin at front axle support
91	-	Hex. -hd. screw M 10x15 DIN 933-8 G	3	
92	120 460 10 19	Steering intermediate lever	1	

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
93	-	Sealing ring A 18x30x7 DIN 6503	1))for steering)intermediate
94	120 463 02 33	Cover	1)lever at)pivot pin
95	181 994 00 10	Locking plate	1)
96	-	Grease fitting A 8 DIN 71412	1	
100	121 460 09 05	Steering rod	1	
105	120 997 00 88	Grease fitting	2	
106	120 338 00 57	Sealing cover	2))for drag link
107	120 338 01 97	Boot	2)at pitman arm)and steering
108	120 990 01 55	Castle nut	2)intermediate)lever
109	-	Cotter pin 2x25 DIN 94	2)
		<u>STEERING SHOCK ABSORBER</u>		
110	000 463 15 32	Steering shock absorber	1	
111	120 990 12 01	Hex. -hd. screw	1)for steering)shock absorber
112	-	Lock washer B 10 DIN 127	1)at drag link)
113	-	Hex. nut M 10x1 DIN 936-5 S	1)
114	120 990 09 40	Washer	1))for steering
115	-	Lock washer B 10 DIN 127	1)shock absorber)at side member
116	-	Hex. nut M 10x1 DIN 936-5 S	1)half