



Table 48

DRIVER'S SEAT

Group 91

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>DRIVER'S SEAT</u>		
1	10 120 910 39 01	Driver's seat, left)ready for installation)with guide rails and)shift lock; driver's	1)
-	10 120 910 40 01	Driver's seat, right)seats, left and right)are installed upon)special request instead)of driver's seat bench	1)state colour)of interior)lining and)body No.)when ordering
2	10 120 910 16 30	Seat cushion, left)with	1)
-	10 120 910 17 30	Seat cushion, right)shift lock	1)
3	10 120 910 09 22	Seat cushion frame, left	1)without
-	10 120 910 10 22	Seat cushion frame, right	1)shift lock
4	10 186 910 03 29	Reinforcement angle	4	
6	10 187 912 01 12	Stop angle, left	1	
7	10 187 912 02 12	Stop angle, right	1	
8	10 136 919 01 36	Guide rail, inner	2	
9	10 136 919 02 36	Guide rail, outer	2	
-	-	Lens-hd. rivet 6 x 10 DIN 662 (for guide rail at seat cushion frame)	4	
10	10 120 910 05 40	Spring core, left	1	
-	10 120 910 06 40	Spring core, right	1	

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
11	10 120 914 01 14	Rubber fiber layer, left	1) for driver's seat cushion
-	10 120 914 02 14	Rubber fiber layer, right	1	
12	000 984 20 61	Clamp 1.4 dia. (for layer at spring core)	18	
13	10 120 910 07 46	Cover (sewn) (for left driver's seat cushion)	1) state colour and body No. when ordering
-	10 120 910 08 46	Cover (sewn) (for right driver's seat cushion)	1	
14	10 120 910 17 05	Adjuster (for driver's seat, left)	1	
15	10 120 910 18 05	Adjuster (for driver's seat, right)	1	
16	12 136 919 00 60	Handle (for adjuster)	2	
-	-	Countersunk screw S 4, 8x16 DIN 7982	12) for adjuster at seat cushion frame
-	000 994 15 45	Nut	6	
20	10 120 910 17 32	Back rest (for driver's seat, left and right)	2) state colour and body No. when ordering
21	10 120 910 02 34	Back rest frame (for driver's seat, left and right)	2	
22	10 120 910 01 56	Back rest rail, left	2) for left and right driver's seat
23	10 120 910 02 56	Back rest rail, right	2	

Table 48

DRIVER'S SEAT

Group 91

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
24	10 120 910 06 41	Spring core	2	
25	10 120 914 02 16	Rubber fiber layer (for driver's seat back rest)	2	
26	000 984 20 61	Clamp (for layer at spring core)	20	
28	10 120 910 06 47	Cover (sewn) (for back rest, left and right)	2	state colour and body No. when ordering
29	136 988 02 78	Clamp (for cover at back rest frame)	22	
30	10 120 910 02 39	Lining (for driver's seat back rest)	2	state colour and body No. when ordering
-	-	Lens-hd. countersunk screw S 3, 9x13 DIN 7983 chromium-plated	4)) for lining at) reinforcement) rail
31	000 985 06 62	Countersunk washer chromium-plated	4))
32	10 120 919 00 15	Swivel pin	4))
33	10 120 919 00 23	Rosette, chromium-plated	4))
-	-	Lock washer B 10 DIN 137	4) for back rest) at seat cushion
-	-	Lens-hd. countersunk screw AM 10x20 DIN 91, chrom. -plated	4)))
34	10 120 919 00 13	Washer, chromium-plated	4)))
-	-	Toothed washer V 6, 5 DIN 6797	4)

Table 48

DRIVER'S SEAT

Group 91

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
-	-	Lens-hd. countersunk screw AM 6x12 DIN 91, chrom. -plated	4) for back rest) at seat) cushion
35	191 991 00 35	Supporting ring	4	
36	10 120 919 01 18	Support, chromium-plated (for back rest)	4	
37	000 987 89 40	Buffer	4	
-	-	Lens-hd. countersunk screw AM 10x25 DIN 91 (for support at seat cushion frame)	4	
38	10 120 919 01 12	Stop angle, left	1) at driver's) seat support
39	10 120 919 02 12	Stop angle, right	1	
-	-	Lens-hd. screw AM 6x15 DIN 7985	4) for stop angle) at driver's
-	-	Lock washer B 6 DIN 127	4	
40	000 990 22 91	Square cage nut	4) seat support
41	10 120 910 01 90	Guide rail, outer	1)
42	10 120 919 03 37	Leaf spring	1)
-	-	Lens-hd. screw AM 4x10 DIN 7985	1) for leaf spring) at guide rail
-	-	Lock washer B 4 DIN 127	1	
-	-	Hex. nut M 4 DIN 934-5 S	1)
43	10 120 910 02 90	Guide rail, inner	1	

