

Table 20

REAR AXLE

Group 35

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>REAR AXLE SHAFT</u>		
70	180 350 13 10	Rear axle shaft, left	1	
71	120 401 01 71	Wheel mounting pin	5	
72	180 350 14 10	Rear axle shaft, right	1	
73	120 401 01 71	Wheel mounting pin	5	
74	180 981 00 25	Annular grooved bearing	2) for rear axle shaft)
75	183 353 03 73	Locking plate	2	
76	153 357 00 26	Grooved nut	2	
77	-	Hex. -hd. screw M 10x22 DIN 933-8 G	4	
78	-	Hex. -hd. screw M 7x22 DIN 933-8 G	4	
79	-	Hose clamp S 9 N 262	2	
80	-	Hose strap 9x0, 4 N 263	a.r.	state length when ordering
81	180 421 08 01	Brake drum with radial fins	2	
82	120 990 00 59	Collar nut	4	see also group 33 and 40
		<u>REAR AXLE SUSPENSION</u>		
85	180 351 06 74	Pin (for rear axle suspension)	1	

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
86	180 351 01 53	Sleeve (between rear axle tube support and pin)	2	
87	180 351 05 52	Washer 2.0 mm thick (for rear axle tube, exterior)	2	
88	180 351 13 52	Shim 1.9 mm thick)	2)
-	180 351 14 52	Shim 2.0 mm thick)	2)
-	180 351 15 52	Shim 2.1 mm thick)	2)
-	180 351 16 52	Shim 2.2 mm thick) optional	2) between rear axle tube and rear axle housing, interior
-	180 351 17 52	Shim 2.3 mm thick)	2)
-	180 351 18 52	Shim 2.4 mm thick)	2)
-	180 351 19 52	Shim 2.5 mm thick)	2)
89	180 351 03 51	Washer (on pin at rear axle tube support, exterior)	2	
90	180 351 09 86	Rubber ring (above shims)	4	
91	180 351 00 74	Key	1) for pin at rear axle housing
92	-	Lock washer 88 DIN 127	1)

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
110	120 352 07 65	Rubber mounting (for thrust arm, rear)	2)
111	120 352 05 76	Tightening washer (rubber mounting, wheel side)	2)
112	120 352 06 76	Tightening washer (rubber mounting, screw side)	2) for thrust arm) at rear axle) tube
113	120 994 04 12	Locking plate	2)
114	120 990 00 01	Hex. -hd. screw	2)
115	121 351 01 86	Rubber mounting with bushing	1)
116	180 351 10 45	Tightening washer	1) for rear axle) suspension,) top at body
117	180 351 03 73	Locking plate	1)
118	180 990 02 51	Hex. nut M 22 x 1, 5	1)
120	180 351 05 86	Rubber ring, bottom (for rear axle suspension, bottom at body)	1	
121	180 351 01 96	Cross strut	1)
122	180 351 05 40	Shackle))) optional)	1) for rear axle) suspension at) body floor
-	180 351 14 40	Shackle))) for cross strut	1)
123	180 351 04 40	Shackle))) optional)	1)
-	180 351 13 40	Shackle))	1)
124	-	Hex. -hd. screw M 12x1, 5x25 DIN 961-8 G (for shackle at cross strut)	1	

Table 20

REAR AXLE

Group 35

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
125	-	Lock washer B 12 DIN 127	1	} for shackle } at cross strut
126	-	Hex. nut M 12x1, 5 DIN 934-5 S	1	
127	-	Hex. -hd. screw M 12x1, 5x35 DIN 960-8 G	1	} for cross strut } at casing
128	-	Lock washer B 12 DIN 127	1	
129	180 351 00 48	Rubber mounting	1)
130	180 351 00 76	Washer)) for cross strut	1	
131	180 351 06 53	Spacer tube)	1	
132	180 351 07 44	Rubber buffer	2	
133	180 351 03 43	Cup (for cross strut)	2	
134	-	Lock washer B 12 DIN 127	1)for seat,)rubber buffer
135	-	Hex. nut M 12 x 1, 5 DIN 934-5 S	1	
136	120 352 08 65	Rubber mounting (for thrust arm, front)	2)for thrust arm)at body
137	120 352 05 67	Seat (for rubber mounting)	2	
138	120 352 00 72	Collar nut	2	
139	-	Cotter pin 3 x 25 DIN 94	2)

10/024