

Table 28

STEERING

Group 46

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
16	-	Hex. -hd. screw M 8x20 DIN 933-8 G	2)for steering)housing cover)at steering)housing
16a	-	Hex. -hd. screw M 8x25 DIN 933-8 G	2	
17	120 462 01 85	Pressure sleeve	1	
18	120 993 24 01	Pressure spring	1	
19	120 461 01 08	Pressure screw	1	
20	120 990 04 51	Hex. nut	1	
21	186 460 05 15	Cable tube	1	
22	120 997 11 40	Sealing ring (at cable tube, top)	1	
23	-	Screw plug AM 10x1 DIN 7604 (for locking steering housing cover after adjustment of front wheels)	1	
<u>PITMAN ARM</u>				
25	120 463 05 01	Pitman arm	1	
26	-	Castle nut M 22x 1,5 DIN 937-5 S	1)for pitman arm)at steering
27	-	Cotter pin 5x40 DIN 94	1	
<u>STEERING COUPLING</u>				
28	120 460 08 10	Steering coupling with ground connection	1	