



Table 27

BRAKES, PISTOL-GRIP HAND BRAKE

Group 42

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>PISTOL-GRIP HAND BRAKE</u>		
1	120 420 17 88	Pawl rod, complete	1	
2	120 427 00 86	Stop ring	1	
3	120 991 00 61	Guide pin (for pawl rod in guide tube)	1	
4	120 420 10 12	Brake lever, complete with bushing	1	
5	120 427 04 50	Bushing	1	
6	187 990 08 40	Washer	1)for brake lever)at pin,)body
7	120 427 03 74	Pin	1	
8	120 420 04 85	Centre brake cable	1	
10	120 420 04 86	Bracket	1	
11	187 427 00 19	Wing nut (for hand brake adjustment)	1	
12	-	Pin 8 f8x18x15 DIN 1434-5 S	1)for centre brake)cable at com -
13	-	Cotter pin 2 x 12 DIN 94	1	
14	180 993 14 10	Release spring (for compensating lever)	1	
15	-	Cotter pin 1, 5x12 DIN 94 (for locking centre brake cable in rope guide)	1	
16	120 420 01 91	Compensating lever for hand brake	1	

