



Table 8

ELECTRICAL EQUIPMENT AT ENGINE

Group 15

| Fig. No. | No. of spare part | Denomination | Quantity | Remarks |
|----------|-------------------|---|----------|---|
| | | <u>STARTER MOTOR</u> | | |
| 1 | 000 151 77 01 | Starter motor with push button operation | 1 | |
| 2 | 000 151 20 13 | Roller freewheel with pinion | 1 | |
| 3 | 000 152 10 11 | Solenoid switch, starter | 1 | |
| 4 | 000 151 14 14 | Set of carbon brushes (4 pieces) | 1 | |
| 5 | 000 151 05 93 | Pressure spring (for carbon brush) | 4 | |
| 6 | 000 151 07 50 | Bushing in drive bearing | 1 | |
| 7 | 000 151 08 50 | Bushing in collector bearing | 1 | |
| 8 | 120 151 00 12 | Intermediate flange (at starter motor) | 1 |))) |
| 9 | - | Hex. -hd. screw M 12x80 DIN 931-8 G | 2 |))for starter motor)at clutch hous- |
| 10 | - | Washer 13 DIN 433 | 2 |)ing) |
| 11 | - | Lock washer B 12 DIN 127 | 2 |)) |
| 12 | - | Hex. nut M 12 DIN 934-5 S | 2 |)) |
| | | <u>GENERATOR</u> | | |
| 13 | 000 154 48 02 | Generator | 1 | |
| 14 | 000 154 27 14 | Set of carbon brushes (2 pieces) | 1 | |
| 15 | 000 154 06 93 | Pressure spring (for carbon brush) | 2 | |

10/024