

Table 11

ENGINE SUSPENSION

Group 22/24

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
		<u>ENGINE SUSPENSION, FRONT</u>		
1	121 220 08 16	Engine support, front, left	1	
2	121 220 09 16	Engine support, front, right	1	
3	-	Lock washer B 8 DIN 127	3)for engine)support at)cylinder)crankcase
4	-	Hex. -hd. screw M 8x18 DIN 933-8 G	3	
5	120 223 04 12	Rubber mounting, left	1	
6	120 223 05 12	Rubber mounting, right	1)for engine sus-)pension, front
7	-	Lock washer B 12 DIN 127	2	
8	-	Hex. -hd. screw M 12x40 DIN 931-8 G	2)for rubber)mounting at)engine support
9	-	Lock washer B 8 DIN 127	4	
10	-	Hex. -hd. screw M 8x15 DIN 933-8 G	4)for rubber)mounting at)front axle)support
		<u>ENGINE SUSPENSION, REAR</u>		
15	121 223 18 04	Engine support, rear, left	1	
16	121 223 19 04	Engine support, rear, right	1	
17	-	Lock washer B 8 DIN 13	4	
18	-	Hex. -hd. screw M 8 x 25 DIN 933-8 G	4	
19	120 223 04 12	Rubber mounting, left (for engine suspension, rear)	1	

Table 11

ENGINE SUSPENSION

Group 22/24

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
20	120 223 05 12	Rubber mounting, right (for engine suspension, rear)	1	
21	121 220 00 71	Screw (for rear engine suspension)	2))for rubber)mounting
22	121 987 00 39	Rubber buffer	2)at engine)support
23	-	Hex. nut M 12 AGGN 14441	2)
24	121 224 00 82	Bellows) for engine	2	
25	121 224 00 84	Sheet metal plate) mounting	2	
26	-	Hex. -hd. screw M 8x15 DIN 933-8 G	4))for rear rubber)mounting at
27	-	Lock washer B 8 DIN 127	4) front axle) support
28	-	Hex. nut M 8 DIN 934-5 S	4)