

Table 18

FRONT AXLE

Group 33

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
94	-	Hex. nut M 12x1, 5 DIN 934-5 S (for wishbone, top at front axle support)	4	
		<u>FRONT AXLE SUSPENSION</u>		
95	180 333 02 65	Rubber buffer, in one piece (for mounting front axle support, front)	1)
)
)
96	120 333 19 65	Rubber buffer, bottom	1) for front sus-
97	120 333 04 53	Spacer sleeve	1) pension of
98	120 330 01 55	Plate	1) front axle
99	120 994 00 13	Locking plate	1) support at
100	120 990 14 01	Hex. -hd. screw	1) body
101	180 333 01 65	Rubber buffer, in one piece (for mounting front axle support, rear)	2)
)
)
102	120 333 19 65	Rubber buffer, bottom	2)
103	120 333 04 53	Spacer sleeve	2) for rear sus-
104	120 330 01 55	Plate	2) pension of
105	120 994 00 13	Locking plate	2) front axle
106	120 990 14 01	Hex. -hd. screw	2) support at
) body
)
)