

Table 24

BRAKES, REAR WHEEL BRAKE

Group 42

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
16	180 421 03 71	Tightening screw	4)for automatic)brake adjust-)ment at brake)shoe
-	180 990 13 40	Shim	a. r.	
		<u>BRAKE LEVER</u>		
17	180 420 00 42	Brake lever, left	1)for brake an-)chor plate at)rear axle tube
18	180 420 01 42	Brake lever, right	1	
20	000 997 81 47	Sealing ring (in rear axle tube)	2	
21	120 357 01 79	Gasket	2	
22	120 357 00 58	Gasket holder	2	
23	000 997 88 47	Sealing ring	2	
24	-	Lock washer B 7 DIN 127	12	
25	-	Hex. -hd. screw M 7x18 DIN 933-8 G	12	
26	120 993 07 01	Pressure spring	2	
27	120 990 06 40	Washer)	2	
28	120 423 01 56	Washer) for supporting tube	2	
28a	120 990 07 40	Washer)	2	
29	-	Lock washer B 8 DIN 127	2	
30	-	Hex. -hd. screw M 8x15 DIN 933-8 G	2	

Table 24

BRAKES, REAR WHEEL BRAKE

Group 42

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
31	183 423 06 74	Pin	2)) for brake lever at brake shoe)
32	-	Washer 8, 4 DIN 125	2	
33	-	Cotter pin 3x15 DIN 94	2	
34	180 423 02 74	Guide pin	4	
35	-	Lock washer 5 N 55 a	4)) for guide pin at brake anchor plate)
36	-	Washer 5, 3 DIN 125	4	
37	-	Cotter pin 3x15 DIN 94	4	
38	180 993 11 10	Release spring (for rear wheel brake shoe, left)	1	
39	180 993 12 10	Release spring (for rear wheel brake shoe, right)	1	
40	136 423 00 92	Release spring (for brake lever)	2	
		<u>WHEEL BRAKE CYLINDER, REAR</u>		
41	000 420 50 18	Wheel brake cylinder 25.4 \varnothing = 1"	2	
42	000 421 09 90	Stop spring	2	
43	000 421 06 89	Filling piece	4	
44	000 421 00 86	Sealing sleeve	4	
45	000 421 00 83	Piston	4	
46	000 421 00 87	Protective cap	4	
47	000 421 04 88	Pressure pin	4	