

Fig. No.	No. of spare part	Denomination	Quantity	Remarks
39	180 250 00 56	Cover plate for clutch housing	1	
40	-	Hex. -hd. screw M 6x25 DIN 931-8 G	2	) ) )for cover plate
41	-	Washer 6, 4 DIN 125	2	) at clutch )housing
42	-	Lock washer B 6 DIN 127	2	) )
43	-	Hex. nut M 6 DIN 934-5 S	2	)
44	121 250 01 15	Clutch throw-out bearing with throw-out unit	1	
45	121 254 00 10	Throw-out bearing	1	
46	180 293 01 11	Throw-out fork	1	
47	120 993 01 25	Spring clip (for throw-out fork at throw-out unit)	2	
48	-	Snap ring R 16 DIN 71805 (for throw-out fork at ball pin)	1	