

Fitting of Tires

Job No.
40-1

On Models 180 to 220 SE the tires are fitted in the same way as on Model 190.

Balancing of Wheels

Job No.
40-2

Models 180, 180 a, 180 D, 190 D, 190 SL, 220 a, 219, 220 S, 220 SE

The wheels are balanced in the same way as on Model 190.

Models 180 b, 180 Db, 190 Db

The wheels are balanced in the same way as on Model 190 b.

Adjustment of Wheels

Job No.
40-3

On Models 180 to 220 SE the wheels are adjusted in the same way as on Model 190. The wheel adjustment data differ for the individual models (see table overleaf).